

Air- Conditioner Interior Shroud Removal on 1981-1982 31'

The placement of the foldette door header track beneath the inside air conditioner shroud on 31' trailers with a rear bath prevents the shroud from being removed in the normal manner for service. The filters may be cleaned by simply lowering the front of the shroud and pulling the filter out.

The following procedures will allow the shroud to be removed completely.

1. On the curbside remove the curved filler piece that fits between the top of the foldette door header and ceiling - two screws through the header holds it in place.
2. Unfasten foldette door from vertical post and slide door to the opposite end of the header.
- * 3. Unfasten the forward end of the rooflocker from the vertical panel. There are two screws through the tambour door guide, two screws along the inside bottom of the locker, and four rivets attaching the forward and center section of the rooflocker to the ceiling.
4. Lift the foldette door header up and twist clockwise to clear the top of the vertical panel. **Note:** If it is not loose there may be a screw into the header from the galley rooflocker.
5. Pull the header toward the rear of the trailer until the shroud can be removed.
- * If the trailer has the optional hanging wardrobe use the following directions in place of step three:

Remove the hanging wardrobe face frame. Attachments are through the forward part of the frame into the vertical panel, through the rear part of the frame into the rooflocker, and one rivet in the bottom of each front corner. Once the attachments are loose the lower and rear face frame can be tapped outward from the inside using a soft block of wood.

If the inside shroud must be removed for warranty purposes, .7 hours labor will be allowed for these procedures.